



Efficient Installation Checklist

Follow these simple install tips for the
Nest Thermostat

Pre-Install Checklist

Contractor

- Determine common wire availability
or use a **Nest Power Connector**

On the contractor's phone

- Create a phone contact with your Nest Pro ID (found on Nest Pro Portal) and VIP support (**855-847-6378**)
→ After entering once, your phone will remember your Nest Pro ID for future installs
- Install the Google Home app
- Utilize **Pro Setup** and enter **Nest Pro ID** during installation

Customer

- Wi-Fi name and password
- Google account (@gmail.com)

On the customer's phone

- Install the Google Home app

Post-Install Checklist

Contractor

Confirm equipment specific settings

- Heat Pump
- Dual Fuel
- Radiant Systems

Explain intelligent settings to customer

- Eco Temps
- Home and Away Routines, Presence Sensing
- HVAC System Health Monitor

On the customer's phone (optional)

- Adjust any available advanced Pro settings in the Google Home app

Customer

- Add thermostat to the Google Home app
- Follow Guided Setup to adjust Schedules and Home/Away Routines
- Enable location services for Presence Sensing
- Add family members and set up additional devices for enhanced presence detection


Adjust any of the **advanced Pro settings** below in the customer's Google Home app


- Minimum Heat On Time: _____
- Compressor Lockout Time: _____
- Minimum Compressor on Time: _____
- Heat Temp Difference: _____
- Cool Temp Difference: _____

- Filter Reminder Frequency: _____
- Aux Heat Upstage Timer: _____
- Aux Heat Droop: _____
- Aux Heat Minimum Delay: _____
- Alternate Changeover Time: _____



Add Additional Home Members




Open the **Google Home** app 
Select **“+”** add icon on top right corner

Select **“Home Member”**


Select **“+”** add icon

Type the **Gmail address** of the home member you want to invite (Note: invited members must have @gmail.com)

Have additional member **accept** invite



Setup Google Assistant



Install compatible **speakers** or **hubs**

Open the **Google Home** app 

Select **“+”** add icon on top right corner

Select **“Devices”** → **Scan QR code** to add device

Toggle microphone button to **“on”** position


To wake up devices, say the prompts; **“Hey Google”**, or **“Ok Google”** and follow with commands like; **“Start the fan”** or **“Set my hallway thermostat to 70 degrees”**

Edit the name your **devices** on the Google Home app



Need additional support?
nest.google.com/pro/support

Configure the Nest Thermostat




Guided Schedule Set Up:

Use ready-made presets like Comfort, Eco, and Sleep or create custom schedules


In the Google Home App: 

1. Select **Thermostat**
2. Select **“Schedules”**
3. Choose preset to edit time and temperature
4. After you’ve made the changes, select **Done**




Home & Away Routines:

Uses input from activity sensors and your phone’s location to automatically switch the behavior of Nest products in your home when you leave and when you come back.

In the Google Home App: 

1. Select account icon circle on top right corner
2. Select **“Home settings”**
3. Select **“Presence Sensing”**
4. Choose the thermostat(s) to respond
5. **Opt into** presence sensing to improve accuracy



Opt-into HVAC System Health Monitor:

Proactive and intelligent HVAC alerts sent to homeowner in real time

In the Google Home App: 

1. Select **Thermostat**
2. Scroll and select **“Notifications”** or **“System Health Monitor”**
3. Select preferred settings
4. Repeat steps for Rush Hour Rewards, Savings Finder and Seasonal Savings notifications

